



IMPORTANT

READ THIS DOCUMENT BEFORE YOU POWER UP THE CAMERA

Quick Start Guide Secure By Default

This is meant as a quick installation guide to help with the installation process, for more information please read the manual which can be found by scanning the below QR Code.


Please contact Technical Support for any product issues or troubleshooting during or after installation:
email: techsupport@360visiontechnology.com or phone: 01928 246104.

For anything else please contact sales: salesadmin@360visiontechnology.com or phone: 01928 570000.


WARNING: FAILURE TO REMEMBER THE CORRECT PASSWORD WILL RESULT IN THE UNIT BEING RETURNED TO 360 VISION TECHNOLOGY TO BE RESET, INCURRING A COST.




Browse to the default web page 192.168.1.187 using a web browser with a cleared cache, then enter a username and an 8-digit password then repeat the password, click login:-
(Alphanumeric and special characters allowed).




A very weak password option will then give the option to proceed by selecting 'NO' or 'YES' to change it:-




Select 'OK' on this screen to access the full camera configuration:-




On the 'Basic Setup' screen put a tick in the 'Full Setup' box and click ok:-




Then select 'Yes' to enable the full setup:-



A full camera browser page will then load with all the tab options to the left, no live video will be displayed until the next step.



By selecting the 'Network' option this screen will give all the options for selecting how the camera is to be used by putting a tick in the relevant boxes then select 'OK'.



- RTSP Enabled = To display the RTSP stream
- No Authentication = Removes the Authentication on RTSP streams.
- Snapshot Enabled = Enables the option to use Snapshot.
- No Authentication = Removes the Authentication on Snapshot.
- ONVIF Enabled = Enables ONVIF Stream.
- SDK Enabled = Enables 360 SDK options.